

Stereoping MidiTools ChordTranslator CC-Table		
for Roland JX-8P, Firmware Version: 1.0		
CC#	Parameter	Notes
11	Cutoff	
12	DCO1 Waveform	
13	DCO1 Range	
14	DCO1 Tune	
15	DCO1 Pitch Env amount	
16	DCO1 LFO Amount	
17	DCO1 Level	
18	DCO2 Waveform	
19	DCO2 Range	
20	DCO2 Tune	
21	DCO2 Fine tune	
22	Corssmod Mode	
23	DCO2 Pitch Env amount	
24	DCO2 LFO Amount	
25	DCO 2 Level	
26	Resonance	
27	VCF Env Amount	
28	VCF Env Mode	Env1 / -Env1 / Env2 / -Env2
29	VCF Env Dynamics	Off / 1 / 2 / 3
30	VCF Highpass	
31	VCF Keyfollow	
32	unused	
33	VCF LFO amount	
34	LFO Shape	Sine / Square / Random
35	LFO Delay	
36	LFO Speed	
37	DCO2 Level Env Amount	
38	DCO2 Level Env Mode	Env1 / -Env1 / Env2 / -Env2
39	DCO2 Level Env Dynamics	Off / 1 / 2 / 3
40	VCA Level	
41	VCA Mode	Gate / ENV2
42	ENV1 Attack	
43	ENV1 Decay	
44	ENV1 Sustain	
45	ENV1 Release	
46	VCA Dynamics	Off / 1 / 2 / 3
47	Chorus	Off / 1 / 2
48	ENV2 Attack	
49	ENV2 Decay	
50	ENV2 Sustain	
51	ENV2 Release	
52	Pitch Env Mode	Env1 / -Env1 / Env2 / -Env2
53	Pitch Env Dynamics	Off / 1 / 2 / 3
54	ENV1 Keyfollow	
55	ENV2 Keyfollow	