

**Stereoping MidiTools ChordTranslator CC-Table
for Korg DW-8000, Firmware Version: 1.0**

CC#	Parameter	Notes
11	Cutoff	
12	VCF Env amount	Bipolar: 0=-64 / 63= 0 / 127=+63
13	Resonance	
14	Waveform 1	
15	Waveform 2	
16	Octave 1	
17	Octave 2	
18	Interval OSC 2	
19	Detune OSC 2	
20	OSC Mix	
21	Noise level	
22	MG Speed	
23	MG → OSC	
24	MG → VCF	
25	MG Wave	
26	MG Delay	
27	Autobend Mode	
28	Autobend Time	
29	Autobend Intensity	
30	Portamento	
31	VCF Keytrack	
32	unused	
33	VCF EG Attack	
34	VCF EG Decay	
35	VCF EG Break	
36	VCF EG Slope	
37	VCF EG Sustain	
38	VCF EG Release	
39	VCF EG Velocity	
40	Delay Time	
41	Delay Factor	
42	Delay Feedback	
43	Delay Mod Freq	
44	Delay Mod Intensity	
45	Delay Level	
46	VCA EG Attack	
47	VCA EG Decay	
48	VCA EG Break	
49	VCA EG Slope	
50	VCA EG Sustain	
51	VCA EG Release	
52	VCA EG Velocity	